| B. C. Livi       |                                  | 1-5. | Opening and closing the     |       |
|------------------|----------------------------------|------|-----------------------------|-------|
| 1 Before driving |                                  |      | windows and moon roof       | 77    |
|                  |                                  |      | Power windows               | 77    |
| 1-1.             | Hybrid system22                  |      | Moon roof                   | 80    |
|                  | Hybrid system 22                 |      |                             |       |
|                  |                                  | 1-6. | Refueling                   | 83    |
| 1-2.             | Key information33                |      | Opening the fuel tank cap   | 83    |
|                  | Keys 33                          |      |                             |       |
|                  |                                  | 1-7. | Theft deterrent system      | 88    |
| 1-3.             | Opening, closing and locking     |      | Immobilizer system          | 88    |
|                  | the doors and trunk35            |      | Alarm                       | 90    |
|                  | Smart access system with         |      | Theft prevention labels     |       |
|                  | push-button start35              |      | (U.S.A.)                    | 92    |
|                  | Wireless remote control 47       | 1.0  | C ( ) · ( ) · ·             | 01    |
|                  | Doors 50                         | 1-8. | Safety information          |       |
|                  | Trunk55                          |      | Correct driving posture     |       |
|                  | A.B                              |      | SRS airbags                 | 95    |
| 1-4.             | Adjustable components            |      | Front passenger occupant    | 10    |
|                  | (seats, mirrors,                 |      | classification system       |       |
|                  | steering wheel)58                |      | Child restraint systems     |       |
|                  | Front seats                      |      | Installing child restraints | 117   |
|                  | Driving position memory system60 |      |                             |       |
|                  | Head restraints                  | 2    | When driving                |       |
|                  | Seat belts                       |      |                             |       |
|                  | Steering wheel                   | 2-1. | Driving procedures          | . 128 |
|                  | Inside rear view mirror          |      | Driving the vehicle         |       |
|                  | Outside rear view mirrors        |      | Power (ignition) switch     |       |
|                  | Catalacteal view Hill 1013       |      | Transmission                |       |
|                  |                                  |      | Turn signal lever           |       |
|                  |                                  |      | Parking brake               |       |
|                  |                                  |      | i di kiriy bi ake           | . 17/ |

| 2-2. Instrument cluster  | 148     | 1   |   |
|--|---------|---|---|
| Gauges and meters  | 148     | 3 Interior features                           |   |
| Indicators and warning   |         | 24 11 2 2 2 2 2                               |   |
| lights   |         | 3-1. Using the touch screen 224               |   |
| Multi-information disp   | lay 155 | Touch screen 224                              |   |
| 2-3. Operating the lights a  | nd      | Setting the touch screen 227                  |   |
| windshield wipers  |         | 20 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1       |   |
| Headlight switch   |         | 3-2. Using the air conditioning               | 2 |
| Fog light switch   |         | system and defogger 232                       |   |
| Windshield wipers and  |         | Automatic air conditioning system             |   |
| washer   |         | Rear window and outside rear                  | 2 |
| Headlight cleaner swit   | ch 165  | view mirror defoggers 240                     | , |
| , and the second |         | 33.4  |   |
| 2-4. Using other driving   |         | 3-3. Using the audio system 241               |   |
| systems  | 166     | Audio system type 241                         | 4 |
| Cruise control   | 166     | Using the radio244                            |   |
| Dynamic radar cruise   |         | Using the cassette player 253                 |   |
| control  |         | Using the CD player257                        | _ |
| Intuitive parking assist   |         | Playing MP3 and                               | ) |
| Rear view monitor syst   |         | WMA discs 262                                 |   |
| AVS (Adaptive Variab   |         | Using the DVD player 266                      |   |
| Suspension System).  |         | Playing DVD                                   | 5 |
| Driving assist systems. PCS (Pre-Collision   | 200     | video/audio                                   |   |
| System)  | 206     | Playing video CD                              |   |
|  |         | DVD player and DVD video disc information 285 |   |
| 2-5. Driving information   | 210     | Optimal use of the                            | 7 |
| Cargo and luggage  | 210     | audio/video system 297                        |   |
| Vehicle load limits  |         | Using the AUX adapter 302                     |   |
| Winter driving tips  | 215     | Using the steering                            |   |
| Trailer towing   |         | switches                                      |   |
| Dinahy towing  |         |   |   |

## **TABLE OF CONTENTS**

Index

| 3-4. | Using the hands-free system                |       |  |
|------|--|-------|--|
|      | (for cellular phone)                       |       |  |
|      | Hands-free system                          |       |  |
|      | (for cellular phone)                       |       |  |
|      | Using the Bluetooth $^{\mathbb{R}}$ phone. | 311   |  |
|      | Setting the hands-free                     | 20/   |  |
|      | system                                     | . 326 |  |
| 3-5. | Using the interior lights                  | 352   |  |
|      | Interior lights list                       | . 352 |  |
|      | J  |       |  |
| 3-6. | Using the storage features                 | 355   |  |
|      | List of storage features                   | 355   |  |
|      |  |       |  |
| 3-7. | Other interior features                    | 362   |  |
|      | Sun visors                                 | . 362 |  |
|      | Vanity mirror                              | . 363 |  |
|      | Clock                                      | . 364 |  |
|      | Outside temperature                        | 0/5   |  |
|      | display                                    |       |  |
|      | Ashtrays                                   |       |  |
|      | Cigarette lighter                          |       |  |
|      | Power outlet                               |       |  |
|      | Seat heaters/ventilators                   |       |  |
|      | Armrest                                    |       |  |
|      | Rear sunshade                              |       |  |
|      | Floor mats                                 |       |  |
|      | Trunk features                             |       |  |
|      | Garage door opener                         |       |  |
|      | Compass                                    |       |  |
|      | Lexus Link System                          | . 387 |  |

## 4 Maintenance and care

| 4-1. | Maintenance and care                         | 402   |
|------|--|-------|
|      | Cleaning and protecting the vehicle exterior | . 402 |
|      | Cleaning and protecting the vehicle interior | 405   |
| 4-2. | Maintenance                                  | 408   |
|      | Maintenance requirements                     | 408   |
|      | General maintenance                          | 410   |
|      | Emission inspection and maintenance (I/M)    |       |
|      | programs                                     | 413   |
| 4-3. | Do-it-yourself                               |       |
|      | maintenance                                  | 414   |
|      | Do-it-yourself service                       |       |
|      | precautions                                  | 414   |
|      | Hood   | 417   |
|      | Positioning a floor jack                     | 418   |
|      | Engine compartment                           | . 420 |
|      | Tires  | . 435 |
|      | Tire inflation pressure                      | . 445 |
|      | Wheels                                       | . 449 |
|      | Air conditioning filter                      | 451   |
|      | Electronic key battery                       | . 454 |
|      | Checking and replacing fuses                 | . 456 |
|      | Headlight aim                                |       |
|      | Light hulbs                                  |       |

4

## When trouble arises Vehicle specifications 6-1. Specifications...... 544 If your vehicle needs Maintenance data (fuel, oil level, etc.)...... 544 to be towed......482 If you think something is Fuel information...... 553 wrong......488 Event data recorder...... 489 6-2. Customization ...... 569 5-2. Steps to take in an Customizable features ...... 569 emergency......491 3 If a warning light turns on or a 6-3. Initialization ...... 575 warning buzzer sounds... ....... 491 Items to initialize ...... 575 If a warning message is displayed...... 500 If you have a flat tire (Vehicles For owners with standard tires)...... 517 If you have a flat tire (Vehicles Reporting safety defects for with run-flat tires) ...... 527 U.S. owners...... 578 If the hybrid system will Seat belt instructions for not start...... 528 Canadian owners If the shift lever cannot be (in French)...... 579 shifted from "P" ...... 529 If you lose your keys......530 Index If the electronic key does not operate properly ...... 531 If the 12 volt battery is Abbreviation list ...... 582 discharged ...... 534 If your vehicle overheats....... 538 Alphabetical index..... 584 If the vehicle becomes stuck...... 541 What to do if...... 594